



Model 2100 Series

Electric Thermal Storage Heaters

SETTING THE TIME AND DAY OF THE WEEK:

1. Use the circuit breaker for your heater to power the heater off and back on.
2. Go to the heater, and press and release the "M" button until the faceplate displays "CLOC". Use the up and/or down arrows to set time of day. Time is displayed on a 12-hour clock, with a flashing light between the hours and minutes display to indicate either a.m. or p.m.

NOTE: The Steffes time clock module DOES NOT recognize daylight saving time, so the time will have to be reset when the time changes.

3. Press and release the "M" button until the faceplate displays "dAY". Use the up and/or down arrow to move to the correct day of the week.
4. Press and release the "M" button to return to normal operation.

NOTE: The clock's built-in power back-up is approximately 3 days; thus, it is not recommended to turn off the main power supply (breaker) feeding the heater. Doing so may cause the heater to lose its time and day settings. You can turn off the heater for the summer by repeatedly pushing the down arrow on the face of the heater until OFF is displayed. Press the up arrow button repeatedly to it turn back on.